

McNaughton Laser Guide Assembly



System Includes:

- 1- (A) Laser Support Arm
- 1- (B) Upright Support
- 1- (C) Upright Support Bracket
- 1- Laser Pointer Bushing
- 2- Hex Nuts
- 2- Washers
- 2- Long Set Screws

Step 1:

Mount the center saver blade in the handle. Mount the upright support bracket (C) onto the handle using the long set screws supplied. The set screws should register against the side of the blade.



Step 2:

Place the upright support (B) into the upright support bracket and install the threaded knob.



Step 3:

Mount the laser support arm (A) in the upright support coupler.



Step 4:

Mount the laser pointer in the plastic bushing on the end of the laser support arm (A). **DO NOT** overtighten the set screw as it may damage the laser pointer.



Step 5:

Turn the laser pointer on by rolling the green rubber ring over top of the "ON" button.



Step 6:

Adjust the laser support arm so that the laser dot aligns with the end of the cutter. Once the laser is properly aligned, **make sure every screw is fully tightened.**



Warning: Carefully read and follow laser pointer safety precautions to prevent injury.

